



		_
	THIS DOCUMENT IS SUPPLIED IN STRICT CONFIDENCE AND MUST NOT BE LENT, REPRODUCED OR DISCLOSED TO ANY THIRD PARTY WITHOUT THE WRITTEN CONSENT OF GRAF UK LIMITED	
	DO NOT SCALE - IF IN DOUBT ASK	
	Notice: This drawing is issued only as a guideline and is an estimate of the materials required to construct the drainage system, it should not be used for construction purposes.	
	Graf UK Ltd makes no warranty or guarantee in relation to the suitability of any of the layout details shown on this drawing in relation to a particular scheme.	
	INSTALLATION METHOD:-	4
e nded	 a) Excavate the trench with a safe batter (or stepped) ensuring the footprint allows for sufficient space between tank and the sides. 	
laca	(minimum 500mm around all sides of the tank). b) Mark out the position of the tank including inlets and outlets.	
	 c) Lay min. 50mm of single sized non angular stone (8 to16mm) as a base for the tank. This can be laid to a maximum fall 	
	of 1°.	
	 a) Lay the Geotextile over the base the excavation, overlapping any joins by a minimum of 300mm 	
	b) The Geotextile used must meet the specification stated on the drawing.	
	 a) Assemble EcoBloc Light Crate and Baseplate, position leg ends into corresponding holes in the Baseplate. The crate will only fit in 	
	the correct orientation. Push down firmly to ensure Crate is located correctly. Assemble the row of EcoBloc Flex Crate with baseplates	
1. ST	where inspection run is required. If a Vario shaft is to be included within the tank make sure the Vario Shaft base is in position located	
	(Vario Shaft bases do not not require a crate baseplates). b) Install already assembled Crates and Baseplates onto the	
	geotextile until the first layer is complete. Insert retaining clips into each adjacent Crate.	
	 c) Check and make sure the Row of EcoBloc Flex Crates are in the correct located position where inspection run is required. d) To install the post human of Contemporation for the stall and the 	
	d) To install the next layer of Crates remove from the stack and turn 90° and position directly above the Crate below. Push down firmly to ensure Crate is located correctly.	
_	ensure Crate is located correctly. NOTE: You will need to place an additional row of Ecobloc Light Baseplates directly on top of the EcoBloc Flex crates only . No more	
	base plates are required. e) Continue until all Crates have been installed, ensuring clips are	
	used to secure each Crate. f) Fit Endplates to the sides of each Crate by positioning the bottom	
	in place then pushing firmly on the top section to locate into place.	
	 a) Fix adaptor plates to the sides of the crates in the required position for the inlet. 	
	 b) Cover top and sides with the Geotextile covering the entire tank . c) Install vent pipe connection into the top of the tank at a suitable location 	
	location. d) Backfill around the tank and for 100mm above with non-angular stone. Backfill to finished ground level with suitable material in layers.	
	 e) Connect inlet pipes using appropriate bandseals. f) In order to prevent silt from entering the tank it is recommended 	
	that silt traps or catchpit manholes are installed upstream of any inlet. These should be regularly maintained to avoid the buildup of any silt.	
	N.B. Installation method may vary depending on depth of the tank and is project specific. For more information or technical questions please	
	contact our Technical Department at Graf UK.	
	P2 REVISED NOTES AP 21.09.22	$\left \right $
	P1 LATEST REVISION AP 05.03.21	1
	REV. DESCRIPTION BY DATE	
	(GRAF.) GRAF UK Limited	
	GRAF UK Limited. Regen House, Beaumont Road, Banbury, Oxfordshire. OX16 1RH	
	T: 01608 661500 F: 01295 211333	
	E: info@grafuk.co.uk www.grafuk.co.uk	
	DRAWN : AP DATE : 05.03.2021 CHECKED : MC SCALE : VARIOUS@A3	
	PROJECT	1
	GRAF STANDARD DETAILS	
	DESCRIPTION	
	INFILTRATION TANK	
	LIGHT AND FLEX	
	DRAWING No. REV.	1
	STANDARD DETAIL_ECOBLOC LIGHT & FLEX ONLY_INFILTRATION (Pg.2)	